

Domestic Hot Water Heat Pump

- Operation and Installation Manual -

ATHW-20a/200LW; ATHW-20a/200L; ATHW-20a/300LW; ATHW-20a/300L ATHW-40a/500LW; ATHW-40a/500L

TABLE OF CONTENT

INTRODUCTION	
This manual	1
The unit	1
SAFETY INSTRUCTIONS	2
Warning	2
Caution	
ITEMS INSIDE PRODUCT BOX	5
OVERVIEW OF THE UNIT	6
Parts and descriptions	
Dimensions	7
How to replace the magnesium stick	
Schematic overview of the water and refrigeration circuit	8
INSTALLATION	
Transportation	
Required service space	9
Installation overview	13
Installation positions	
Water loop connection	14
Water affusion and water emptying	15
Wire connection	15
Trial running	15
OPERATION THE UNIT	
User interface and operation	
LED icons	19
WIFI	
PARAMETER CHECKING AND ADUSTMENT	
Parameter list	
Malfunctioning of the unit and error codes	
MAINTENANCE	
TROUBLESHOOTING	
TECHNICAL SPECIFICATION TEMPERATURE SENSOR R-T CONVERSION TABLE	
IEWPERATURE SENSUR R-I CUNVERSION TABLE	

READ THIS MANUAL CAREFULLY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY.KEEP IT IN YOUR FILES FOR FUTUREREFERENCE.
 BEFORE OPERATING THE UNIT, MAKE SURE THE INSTALLATION HAS BEEN CARRIED

BEFORE OPERATING THE UNIT, MAKE SURE THE INSTALLATION HAS BEEN CAR OUT CORRECTLY BY A PROFESSIONAL DEALER. IF YOU FEEL UNSURE ABOUT OPERATION, CONTACT YOUR DEALER FOR ADVICE AND INFORMATION.

INTRODUCTION

This manual

This manual includes the necessary information about the unit. Please read this manual carefully before you use and maintain the unit.

The unit

The hot water heat pump is one of the most economical systems to heat the water for family domestic use. Using free renewable energy from the air, the unit is highly efficient with low running costs. Its efficiency can be up to $3 \sim 4$ times more than conventional gas boilers or electrical heaters.

Waste Heat recovery

Units can be installed near the kitchen, in the boiler-room or the garage, basically in every room which has a large number of waste-heat so that the unit has the higher energy efficiency even with very low outside temperatures during the winter.

Hot water and dehumidification

Units can be placed in the laundry room or clothing room. When it produces hot water it lowers the temperature and dehumidifies the room as well. The advantages can be experienced particularly in the humid season.

Storage room cooling

Units can be placed in the storage room as the low temperature keeps the food fresh.

Hot water and fresh air ventilation

Units can be placed in the garage, gym, basement etc. When it produces hot water, it cools the room and supplies fresh air.

Compatible with different energy sources

Units can be compatible with solar panels, external heat pumps, boilers or other different energy sources.

Ecological and Economical Heating

Units are the most efficient and economical alternative to both fossil fuel boilers and heating systems. By making use of the renewable source in the air, it consumes much less energy.

Compact design

Units are especially designed for offering sanitary hot water for family use. Its extremely compact structure and elegant design are suitable for indoor installation.

Multiple Functions

The special design of the air inlet and outlet makes the unit suitable for various ways of connections. With different ways of installation, the unit can work as just a heat pump but also as a fresh air blower, a dehumidifier, or an energy recovery device.

Other features

Stainless steel tank and a magnesium stick assure the durability of components and the tank. Highly efficient compressor with the R134a refrigerant.

Electrical element available in the unit as a back-up, assuring constant hot water even in extreme cold winters.

SAFETY INSTRUCTIONS

To prevent injury to the user, other people, or property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm ordamage.

Install the unit only when it complies with local regulations, by-laws and standards. Check the main voltage and frequency. This unit is only suitable for earthed sockets, connection voltage 220 ~240 V ~ / 50Hz.

The following safety precautions should always be taken into account:

- Be sure to read the following WARNING before installing the unit.
- Be sure to observe the cautions specified here as they include important items related tosafety.
- After reading these instructions, be sure to keep it in a handy place for future reference.

Warning



Do not install the unit yourself.

Incorrect installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or a specialized installer.

Install the unit securely in a place.

When insufficiently installed, the unit could fall causing injury. The bearing surface should be flat to bear the weight of the unit and suitable for installing the unit without increasing noise or vibration. When installing the unit in a small room, please take measures (like sufficient ventilation) to prevent the asphyxia caused by the leakage of refrigerant.

Use the specified electrical wires and attach the wires firmly to the terminal board (connection in such a way that the stress of the wires is not applied to the sections). Incorrect connection and fixing could cause a fire.

Be sure to use the provided or specified parts for the installation work.

The use of defective parts could cause an injury due to possible fire, electric shocks, the unit falling etc.

Perform the installation securely and please refer to the installation instructions.

Incorrect installation could cause an injury due to possible fire, electric shocks, the unitfalling, leakage of water etc.

Perform electrical work according to the installation manual and be sure to use a dedicated section, fused with 16A.

If the capacity of the power circuit is insufficient or there is an incomplete electrical circuit, it could result in a fire or an electric shock.

The unit must always have an earthed connection.

If the power supply is not earthed, you may not connect the unit.

Never use an extension cable to connect the unit to the electric power supply.

If there is no suitable, earthed wall socket available, have one installed by a recognized electrician.

Do not move/repair the unit yourself.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard. Improper movement or repair on the unit could lead to water leakage, electrical shock, injury or fire.

The unit is no intended for use by children.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Do not tear off the labels on the unit.

The labels are for the purpose of warning or reminding, keeping them can ensure your safe operations.

THE APPLIANCE SHALL BE INSTALLED IN ACCORDANCE WITH NATIONAL WIRING REGULATIONS.

See technical specification table for ambient temperature range and water temperature range. The water pressure range for the appliance is 0.15-0.7MPa.

- The water may drip from the discharge pipe of the one-way safety valve and that this pipe must be left open to the atmosphere.

- The one-way safety value is to be operated regularly to remove lime deposits and to verify that it is not blocked. Please beware of burn, because of the high temperature of water.

Caution



Do not install the unit in a place where there is a chance of flammable gas leaks.

If there is a gas leak and gas accumulates in the area surrounding the unit, it could cause an explosion.

Perform the drainage/piping work according to the installation instruction.

If there is a defect in the drainage/piping work, water could leak from the unit and household goods could get wet and be damaged.

Do not clean the unit when the power is 'ON'.

Always shut 'OFF' the power when cleaning or servicing the unit. If not, it could cause an injury due to the high speed running fan or an electrical shock.

Do not continue to run the unit when there is something wrong or there is a strange smell.

The power supply needs to be shut 'OFF' to stop the unit; otherwise this may cause an electrical shock or fire.

Do not put your fingers or others into the fan, or evaporator.

The inside parts of the heat pump may run at high speed or high temperature, they could cause serious injury. Do not remove the grills on the fan outlet and top cover.

The hot water probable need to mix with cold water for terminal usage, too hot water (over 50 $^{\circ}$ C) in the heating unit may cause injury.

The installation height of power supply should be over 1.8m, if any water may spatter, the unitcan be safe from water.

Fuse specification is T 3.15A 250V Global Warming Potential (GWP) of R134a = 1430. Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.


ITEMS INSIDE PRODUCT BOX

Before starting the installation, please make sure that all parts are found inside the box.


The Unit Box				
Item	Quantity			
Domestic hot water heat pump	1			
Operation and Installation Manual	1			

OVERVIEW OF THE UNIT Parts and descriptions

ATHW-20a/150LW; ATHW-20a/150L; ATHW-20a/200LW; ATHW-20a/200L; ATHW-20a/300LW; ATHW-20a/300L




ATHW-40a/500LW; ATHW-40a/500L



Dimensions

Model: ATHW-**



	150L/150LS	200L/200LS	300L/300LS	500L/500LS
A	Φ 560	Φ 560	Ф640	Ф700
В	Φ177	Φ177	Φ177	Φ177
D	946	1185	1280	1680
E	553	875	1040	1420
F	1489	1750	1845	2250
G	450	450	450	450
Н	737	1025	1140	1520
Ι	270	270	270	270
J	457	600	680	893
К	482	250	250	280
L	32.5	32.5	32.5	32.5
М	35	35	35	35
N	847	1135	1230	1633

Remark:


1) The extra heat source is optional.

2) Add the solar control. While the parameter 14= 1, solar energy control is available. The terminal "TO PUMP" is connected solar energy water pump, "FS" is connected the flow switch of solar water circuit, "SOLAR SENSOR" is testing the temp of solar thermal collector.

3) Electrical anod anti-corrosion system is maitanance free system and mainly consists of controller and titanium electrode, which makes sure the inner wall of the stainless steel tank is always protected against corrosion efficiently.

When the controller reports the related fault of the electronic anode, please contact the local service provider for on-site repair in time. In addition, the system will prohibit auxiliary electrical heater work under the fault state, and the heat pump is only allowed to work for 3 days, after that the whole unit will be locked and cannot continue to work.

Schematic overview of the water and refrigeration circuit



Choose the suitable unit

Please refer to the table below to choose the suitable unit.

Family members	Tank capacity
2 ~ 3 people	150L
4 ~ 5 people	200L
6~ 7 people	300L
More than 8 people	500L

Note: The table is just for reference.

INSTALLATION

- Asked your supplier to install the unit. Incomplete installation performed by yourself may result in a water leakage, electric shock, or fire.
- Indoor installation is highly recommended. It is not allow to install the unit atoutdoor or rain achieving place.
- The installation place without direct sunlight and other heat supplies is recommended. If no way to avoid these, please install a covering.
- The unit must be securely fixed to avoid noise and shaking.
- Make sure that there's no obstacle around the unit.
- In the place where there is strong wind, fix the unit in the locationprotected from the wind.

Transportation


As a rule, the unit is to be stored and/or transported in its shipping container in upright position and without water charge. For a transport over short distance (provided that it is done with care), an inclination angle up to 30 degrees is permitted, both during transport and storage. Ambient temperatures of –20 to +70 degrees Celsius are permitted.

- Transport using a forklift

When transported by a forklift, the unit must remain mounted on the pallet. The lifting rate should be kept to a minimum. Due to its top-heaviness, the unit must be secured against tipping over. To prevent any damage, the unit must be placed on a level surface.

- Manual transport


For the manual transport, a wooden/plastic pallet can be used. Using ropes or carrying straps, a second or third handling configuration is possible. With this type of handling, it is advised that the maximum permissible inclination angle of 45 degree is not exceeded. If transport in an inclined position cannot be avoided, the unit should be taken into operation one hour after it has been moved into final position.



ATTENTION: DUE TO THE HIGH CENTER OF GRAVITY, LOW OVERTURNING MOMENT, THE UNIT MUST BE SECURED AGAINST TIPPING OVER.

Required service space


Below you will find the minimum space required to be able to complete service and maintenance tasks on the units.



Note:

- If air inlet and/or outlet pipes are connected, portion airflow and capacity in heat pump unit will lose.
- If the unit connects with air ducts it should be DN 180mm for pipes or 180mm internal diameter flexible hose. Total length of the ducts should not be longer than 8m or the maximum static pressure should not exceed than 60Pa. Be in mind of bending site of the duct no more than 4m.
- The air outlet pipe needs to be insulated to prevent condensate condensation

Installation overview



Note: Solar heat exchange coil is optional.



- The PT valve must be installed to release pressure. If not, it could cause damage to the unit, or even hurt people
- The one-way safety valve must be installed. If not, it could cause damage to the unit, or even hurt people. The set point of this safety valve is 0.7 MPa. For the installation place please refer to the pipeline connection sketch.
- The condensate water drainage pipe should be installed in a continuously downward direction and in a frost-free environment.

- The water may drip from the discharge pipe of the one-way safety valve and that this pipe must be left open to the atmosphere.
- The one-way safety value is to be operated regularly to remove lime deposits and to verify that it is not blocked. Please beware of burn, because of the high temperature of water.
- The tank water can be drained through the drainage hole on the bottom of the tank.
- After all the pipes installed turn on the cold water inlet and hot water outlet to fill the tank. When there is water normally following out from water outlet, the tank is full. Turn off all valves and check all pipes. If any leakage, please repair.
- If the inlet water pressure is less than 0.15MPa, a pressure pump should be installed at the water inlet. For ensure the long safety using age of tank at the condition of water supply hydraulic higher than 0.7MPa, a reducing valve should be mounted at the water inlet pipe.
- Filters are needed in the air inlet. If the unit is connected with ducts, filter in there must beput forward to the air inlet of duct.
- Tofluently drain condensate water from evaporator, please install the unit at the horizontal floor. Otherwise, please make sure the drain vent is at the lowest place. Recommending the inclination angle of unit to be ground should no more than 2degree.

Installation positions

(1) Waste heat can be useful heat

Units can be installed near the kitchen, in the boiler-room or the garage, basically in every room which has a large number of waste-heat so that the unit has the higher energy efficiency even with very low outside temperatures during the winter.



(2) Hot water and dehumidification

Units can be placed in the laundry room or clothing room. When it produces hot water it lowers the temperature and dehumidifies the room as well. The advantages can be experienced particularly in the humid season.



(3) Solar panel or external heat pump could be the second heat source Units can work with solar panel, external heat pump, boiler or other different energy source.



NOTE:

- · Choose the right path to move the unit.
- · This unit complies with the relevant technical standards of electrical equipment.

Water loop connection

Please pay attention to the below points when connecting the water loop pipe:

- 1. Try to reduce the water loop resistance
- 2. Make sure there is nothing in the pipe and the water loop is smooth, check the pipe carefully to see if there is any leak, and then pack the pipe with the insulation.
- 3. Install the one way valve and safety valve in the water circulation system according to scretch on page 12. The specification of the one way safety value is 0.7Mpa. Make sure the direction marked on the valve align with the water flow direction.
- 4. The nominal pipe wide of the field- installed sanitary installations must be selected on the basis of the available water pressure and the expected pressure drop within the piping system.
- 5. The water pipes may be of the flexible type. To prevent corrosion damage, make sure that the materials used in the piping system are compatible.
- 6. When installing the pipe-work on the customers' site, any contamination of the piping system must be avoided.

Water affusion and water emptying

Water Affusion:

If the unit is used for the first time or used again after emptying the tank, please make sure that the tank is full of water before turning on the power.

- Open the cold water inlet and hot water outlet.
- Start the water affusion. When there is water normally flowing out from the hot water outlet, the tank is full.
- Turn off the hot water outlet valve and water affusion is finished.

ATTENTION: Operation without water in water tank may result in damage of auxiliary e-heater!

Water emptying:

If the unit needs cleaning, moving etc, the tank should be emptied.

- Close the cold water inlet
- Open the hot water outlet and open the manual valve of drainpipe
- Start the water emptying.
- After emptying, close the manual valve.

Wire connection

- The specification of the power supply wire is 3*2.5 mm².
- There must be a switch when connecting the unit to the power system. The current of the switch is 16A.
- The unit must be installed a Creepage Breaker near the power supply and must be effectively earthed. The specification of the creepage breaker is 30mA, less than 0.1sec.

THE APPLIANCE SHALL BE INSTALLED IN ACCORDANCE WITH NATIONAL WIRING REGULATIONS.


Trial running

Checks before trial running

- Check both the water in the tank as well as the water pipe connection.
- Check the power system, make sure that the power supply is normal and the wire connection is ok.
- Check the inlet water pressure, make sure that the pressure is sufficient (above 0.15Mpa).
- Check if any water flows out from the hot water outlet, make sure that the tank is full of water before turning on the power.
- Check the unit; make sure everything is ok before turning 'ON' the power of the unit, check the light on the wire controller when the unit runs.
- Use the wire controller to start the unit.
- Listen to the unit carefully when turning 'ON' the power of the unit. Turn the power 'OFF' when you hear an abnormal sound.
- Measure the water temperature, to check the undulation of the water temperature.
- Once the parameters have been set, the user cannot change the parameters optionally. Please use a qualified service person to do this.

OPERATION THE UNIT

User interface and operation



Operations

1. Power 'ON'

When turning 'ON' the power, whole icons are displayed on the controller screen for 3 seconds. After checking if everything is ok, the unit enters into the standby mode.



2. 🔱 button

Press this button and keep for 2 seconds when the unit is standby, the unit can be turned 'ON'. Press this button and keep for 2 seconds when the unit is running, the unit can be turned 'OFF'. Short press this button to entry or exit the parameter setting or checking.

٢
KATER TEMP
10:35

3. \square And \square buttons

- These are the multi-purpose buttons. They are used for the temp setting, parameter setting, parameter checking, clock adjustment and adjustment of the timer.
- During running status, press 🔺 or 🔻 button to adjust the setting temperature directly.
- Press these buttons when the unit is on clock setting status, the hour(s) and the minute(s) of the clock time can be adjusted.
- Press these buttons when the unit is on timer setting status, the hour(s) and the minute(s) of the timer 'ON'/'OFF' can be adjusted.
- Press ▲ and ▼ buttons at the same time and hold for 5 seconds, the buttons are locked.
- Press ▲ and ▼ buttons at the same time and hold for 5 seconds again, the buttons are unlocked.

4 Øbutton

Clock setting:

- After power on, short press 🖾 button to entry the clock setting interface, hour and minute icons "88:88" flash together;

- Short press \square button to switch hour/minute setting, press the \blacktriangle and \checkmark buttons to set the exact hour(s) and minute(s);

- Press 🖾 button again to confirm and exit.

Timer setting:

- After power on, long press Dutton for 5 seconds to entry the timer setting interface, the timer on icon and hour icon "88:" flash together;

- Press the \blacktriangle and \triangledown buttons to set the exact hour(s).

- Press 0 button to transfer to minute setting, minute icon ":88" flash, press the \checkmark and \checkmark buttons to set the exact minute(s).

- Press 🖾 button again to transfer to timer off setting, the timer off icon 🔜 and hour icon "88:" flash together.

- Press the \blacktriangle and \checkmark buttons to set the exact hour(s).

- Press 0 button to transfer to minute setting, minute icon ":88" flash, press the \blacktriangle and \checkmark buttons to set the exact minute(s).

- Press Dutton again to save and exit the timer setting interface.

Press 🖾 button to cancel the timer settings during the timer 'ON' (or timer 'OFF') programming.

NOTE:

- 1) The timer 'ON' and timer 'OFF' functions can be set at the same time.
- 2) The timer settings are repeating.
- 3) The timer settings are still valid after a sudden power cut.

6 🛛 🖾 button

1) When the heat pump is ON, press this button to turn 'ON' the electrical heater. The heater icon icon will be showed, and the electrical heater will work according to the control program (parameter 3).

2) When the heat pump is ON, press this button and hold for 5 seconds to enable or disable the fan ventilation function.

3) When the heat pump is OFF, press this button to entry E-heater heating mode.

7 🔯 button

Check the temperatures and EXV open steps(running parameter)
 -Press this button to entry temp and EXV open step checking.

-Press the ▲ and ▼ buttons to check the temp sensor values and EXV open steps (parameters A-H).

2) Check the system parameters

-In any status, press this button and hold for 5 seconds, entry the system parameter checking interface.

-Press the ▲ and ▼ buttons to check the system parameters.

- 3) Adjust the system parameters
 - When the unit is off, press 🖾 for 5 seconds, entry the parameter checking interface.
 - Press ▲ or ▼ button to select the parameter, and press 🗟 button to confirm it.

- Press the ▲ and ▼ buttons to adjust the selecting parameter, then press ¹/₂ to confirm the setting.

If no action to the buttons for 10 seconds, the controller will exit and save the setting automatically.

NOTE: The parameters have been set; the user cannot change the parameters optionally. Please ask a qualified service person to do this when required.

8 Error codes

During standby or running status, if there is a malfunction, the unit will stop automatically and show the error code on the left screen of the controller.

	NATER TEMP
ienor	10:35

LED icons

1. Hot water available

The icon indicates that the domestic hot water temperature reaches the set point. The hot water is available for use. Heat pump is standby.

2. Fan ventilation 🔁

The icon indicates that the fan ventilation function is enabled.

When the unit is on, press the subtraction and hold it for 5 seconds the fan ventilation function can be enabled or disabled. If this function is enabled the fan will continue working to ventilate the air, when the water temperature reaches the set point and unit is standby. If this function is disabled the fan will stop, when the water temperature reaches the set point and unit is standby.

3. Electrical heating 🙆

The icon indicates that the electrical heating function is enabled. The electrical heater will work according to the control program.

4. Defrosting 📓

this icon shows the heat pump is under defrosting

5. Heating 🚨

this icon shows the heat pump is working

6. Key lock 🛅

The icon indicates the key lock function is enabled. The keys cannot be operated until this function is disabled.

7. Left temperature display

The display shows the setting water temperature.

When checking or adjusting the parameters, this section will display the relating parameter number.

8. Right temperature display

The display shows the current downside temperature of the water tank. When checking or adjusting the parameters, this section will display the related parameter value.

In case any malfunction occurs, this section will display the related error code.

9. Time display

The display shows the clock time or timer time.

10. Timer 'ON' 🔡

The icon indicates that the timer 'ON' function is enabled.

11. Timer 'OFF' 🔡

The icon indicates that the timer 'OFF' function is enabled.

12. Error 🚟

The icon indicates there is malfunction.

Extra PV control function:

Add PV switch in the main control board;

When the parameter 17 select 0: It is in manual setting status, can be directly operate the \blacktriangle and \triangledown button of the wire controller to change the set temperature;

When the parameter 17 select 1: it is auto setting status, the set temperature will proceed the automatically control according to the parameters of 18/19 and the status of PV Switch; Direct manipulation + / - keys do not change the set temperature, but will response to the operation action by sound;

When the PV Switch is closed, set temperature directly change to the set value of parameter 18; When the PV Switch is disconnected, set temperature directly change to the set value of parameter 19.

Solar control function:

The system has integrated the solar control function:

After the unit turn on, the system will automatically check the temperature of the solar collector (T6), and compare with the water tank temperature inside, when the condition is met, the solar pump will automatically start to work.

WIFI

Install the App

Method I:

Scan the QR code to download the App, Smart Life-Smart Living, for iOS system and Android system. Finish the download and install it.


Notes: Please scan the QR code by browser for Android system.



Method 2:

Register

Search the App, Smart Life-Smart Living, in App store for iOS system or in Google Play Store for Android system. Finish the download and install it.



After click "Allow", enter next interface.




Click "Agree". Choose country and type mobile number or email address to get the message of verification code. Please set the password, and remember it.

Privacy Poli	су	
We pay high attention to the p personal information. To fully collect and use your personal revised the Privacy Policy in d	present how we information, we	Register
compliance with the latest law regulations. By clicking I Agre	is and	Bulgaria +359
you have fully read, understoo all the content of the revised I Please take your time to read Policy. If you have any questio contact us anytime.	Privacy Policy. the Privacy	Mobile Namber/Email
Privacy Policy		Carl Martine Carlos
Disagree	Agree -	
Enter Verificat	tion Code	Set Password
		Password contains 6 to 20 characters, including littlers and digits
		Date
Verification code has been sent phone 水水水水水水 和sen		

App configuration

After setting the password to log in the app, add the device. Click "Large Home Applications" and "Water Heater" to next interface.

2	l.	$0 \oplus$	<	Add Manually	Auto Scan	E
			Electrical Engineeri	•	-	1
			Lighting	Ventilation System	Air Conditioner	Refrigerator
	$\left[+\right]$		Large Home	m 💿	-	
	No devices, please add		Small Home Ap	Washing Machine	Air Conditioner (ZigBer)	Water Heato
	-Jm	γ	Kitchen Appliance			
			Security & Sensor			
			Exercise & Health			
	÷Ċ (0	Others			
Home	s Smart	О Ме				



Please connect the Wi-Fi module with heat pump unit. At the same time, please keep the module and mobile devices can receive the same networks.



Power on the heat pump unit, and keep pressing the timer button and the increase button at the same time for 5 seconds. The SET icon will be flashed. When the Wi-Fi indicator keeps fast-flashing, please click the "Confirm indicator rapidly blink".



Notes: when the icon of set flashes quickly, it mean the controller is in the Wi-Fi mode. When it flashes slowly, it means the controller is connecting with the App. During the connection, if the icon of set is extinguished, it means the App connection with the unit is finished.


If the mobile is not connected with Wi-Fi from the router, the interface will be automatically skipped to the following interface.



Click "go to connect" to set the mobile's Wi-Fi. If the mobile is already connected with the Wi-Fi from the router, please type the password and click "Confirm" in the next interface.

	2.4Gнz 5Gнz ✓ ×	
Or	ly 2.4 GHz Wi-Fi networks	
((1-	TP-LINK_5G_B7A6	-
۵	Password	0

After click "Confirm", the Wi-Fi module, mobile device and Wi-Fi router begin to be connected. Finsih the connecting, and the interface will be skipped to the next interface.



In this interface, the device (heat pump unit) can be named as you want. Click "Done" to finish the App installation. The screen of the mobile device will display the app control interface.



App operation

Device Information		<
Tap-to-Run and Automation		>
Device Offline Notification		
Offline Notification	0)
Others		
Share Device		>
FAQ & Feedback		>
Add to Home Screen		>
Check Device Network	Check Now	>
Check for Firmware Upgrade		>
Remove Device		

2. Temperature setting bar

Move the ball to left or right by finger to set the setting temperature.


3. 75° Setting temperature value

This value will be changed according to the location of the ball in the temperature settingbar.

Tank temp: 24°C Water temperature value in thetank.
 This value is detected by the water temperature sensor in the water tank.

(M) 5. Mode button

Click the mode button to enter the mode interface. In the mode interface, two modes incluiding heating mode and heating fan mode can be selected.




6. Auto Mode Running mode icon of the ehat pump unit

According to the mode selection, this icon will display Auto Mode, Cooling Mode and Heating Mode.

(O) Timer button

7.


Press this button to enter timer interface.




Click "Add" to set the schedule.

< A	dd Sche	dule	Save
11	51		
12	52		
1	53	AM	
2	54	PM	
3	55		
Repeat		ŝ	Sun. Mon. >
Note			>
Notification			\bigcirc
ON/OFF			on >

Please in this interface, setting the time and day for timer on and timer off. After setting, please click "Save" to confirm and save. The timer setting will be displayed in next interface. In ths interface, click "Add Schedule" to add another timer on/off.



Slide the schedule from left to right to delete the schedule.



8. 🕑 On/Offbutton

Click this button to switch on or switch off the heat pump unit.

PARAMETER CHECKING AND ADUSTMENT

Parameter list

Some system parameters can be checked and adjusted by the controller. Below is the parameter list:

Parameter No.	Description	Range	Default	Remarks
0	Tank water setting temp.	10 ~ 70°C	50°C	Adjustable
1	Water temperature gap to restart	2 ~ 15°C	5°C	Adjustable
2	E-heater off tank water temp	10 ~ 85°C	55°C	Adjustable
3	E-heater delay time	0 ~ 90min	6	t * 5 min
4	Week disinfection temperature	50 ~ 70°C	70°C	Adjustable
5	High temp disinfection time	0 ~ 90 min	30 min	Adjustable
6	Defrosting period	30~90 min	45 min	Adjustable
7	Defrosting entry coil temp.	-30 ~ 0°C	-7°C	Adjustable
8	Defrosting exit coil temp.	2 ~ 30°C	13°C	Adjustable
9	Max defrosting cycle period	1 ~ 12 min	8 min	Adjustable
10	Electronic expansion valve adjustment	0/1	1	Adjustable(0-manual,1- auto)
11	Target over-heat degree	-9 ~ 9°C	5°C	Adjustable
12	Steps of manually adjusting the electronic expansion valve	10 ~ 50 step	35 step	Adjustable
13	Disinfection start up time adjusting	0~23	23	Adjustable(hour)
14	Parameter of solar water pump	0/1	1	Adjustable(0 without water pump,1with water pump)
15	Solar water pump star return difference	2-20 ℃	10	Adjustable
16	High temp disinfection frequency	7-28day	7	Adjustable
17	Temperature setting mode	0/1	1	Adjustable(0-manual,1- auto)
18	Set temp with PV	10-70 ℃	60	Adjustable
19	Set temp without PV	10-70 ℃	50	Adjustable
20	When electric anode is defective, heat pump working time	0-7 days	3	Adjustable
21	Upper limit of electric anode voltage	3.5-4.5V	4.0V	Adjustable Actual=set value x 10
22	Lower limit of electric anode voltage	1.0-2.0V	1.5V	Adjustable Actual=set value x 10
А	Lower tank water temp.	-9 ~ 99°C		sting value. Error code P1 will wn in case of a malfunction
В	Upper tank water temp.	-9 ~ 99°C	Actual testing value. Error code P2 w be shown in case of a malfunction	
С	Evaporator coil temp.	-9 ~ 99°C	Actual testing value. Error code P3 w be shown in case of a malfunction	
D	Return gas temp.	-9 ~ 99°C		sting value. Error code P4 will wn in case of a malfunction
E	Ambient temp.	-9 ~ 99°C		sting value. Error code P5 will wn in case of a malfunction
F	Electronic expansion valve step	10 ~ 47 step	N*10 step	
Г			Measured value, if failure, show P6	
н Н	Temp of solar thermal collector	0-140 ℃	Measure	ed value,if failure,show P6

Malfunctioning of the unit and error codes

When an error occurs or the protection mode is set automatically, the circuit board and the wired controller will both display the error message.

Protection/ Malfunction	Error code	LED indicator	Possible reasons	Corrective actions
Standby		Dark		
Normal running		Bright		
Lower tank water temp. sensor failure	P1	☆● (1flash 1 dark)	 The sensor open circuit The sensor short circuit PCB board failure 	 Check the sensor connection Replace the sensor change the PCB board
Upper tank water temp. sensor failure	P2	☆☆● (2 flashes 1 dark)	 The sensor open circuit The sensor short circuit PCB board failure 	 Check the sensor connection Replace the sensor change the PCB board
Evaporator coil temp. sensor failure	P3	☆☆☆● (3 flashes 1 dark)	 The sensor open circuit The sensor short circuit PCB board failure 	 Check the sensor connection Replace the sensor change the PCB board
Return air temp sensor failure	P4	☆☆☆∳● (4 flashes 1 dark)	 The sensor open circuit The sensor short circuit PCB board failure 	 Check the sensor connection Replace the sensor change the PCB board
Ambient temp. sensor failure	P5	☆☆☆☆● (5 flashes 1 dark)	 The sensor open circuit The sensor short circuit PCB board failure 	 Check the sensor connection Replace the sensor change the PCB board
Solar temp. sensor failure	P6	☆☆☆☆☆☆☆☆☆☆●(10 flash1dark)	 The sensor open circuit The sensor short circuit PCB board failure 	 Check the sensor connection Replace the sensor change the PCB board
Electronic anode output open or short circuit	P7			1) check if the water tank has been filled with water

Electronic anode				1) check if the
output voltage exceeds normal working range	P8			water tank has been filled with water
Emergency switch off	EC	only show the protection code	 Connecting wire off PCB board failure 	 According to the physical truth judging whether is normal or not change the PCB board
High pressure protection (HP Switch)	E1	☆☆☆☆☆● (6 flashes 1 dark)	 Too high air inlet temp Less water in the tank The electronic expansion valve assembly blocked Too much refrigerant The switch damaged The uncompressed gas is in refrigerant system PCB board failure 	 Check if the air inlet temp is over the working limited Check if the tank is full of water. If not, charge water Replace the electronic Replace the electronic Applace the electronic Replace a new switch Discharge and then recharge the refrigerant change the PCB board
Low pressure protection (LP Switch)	E2	☆☆☆☆☆☆● (7 flashes 1 dark)	 Too low air inlet temp The electronic expansion valve assembly blocked Too less refrigerant The switch damaged The fan assembly can not work PCB board failure 	 Check if the air inlet temp is over the working limited Replace the electronic Replace the electronic Charge some refrigerant Charge some refrigerant Replace a new switch Check if the fan working when the compressor Working. If not, some problems with the fan assembly change the PCB board

Over heat protection (HTP Switch)	E3	☆☆☆☆☆☆☆● (8 flashes 1 dark)	 Too high tank water temp The switch damaged PCB board failure 	 If the tank water temp is over 85C, the switch will open and the unit will stop for protection. After the water comes to normal temp, Replace a new switch Change the PCB board
Solar thermal collector high tem protection	E4	☆☆☆☆☆☆☆☆☆☆●(11flash1 dark)	 solar water circuit water flow very little or without water flow Related connecting wires off Water pump failure PCB board failure 	 Solar water circuit fluid infusion and exhaust Related connecting wires being reconnected Change the water pump change the PCB board
Water flow failure	E5	☆☆☆☆☆☆☆☆●(9 flash 1dark)	 solar water circuit water flow very little or without water flow Related connecting wires off water pump failure water flow switch failure PCB board failure 	 Solar water circuit fluid infusion and exhaust Related connecting wires being reconnected Change the water pump Change the water flow switch Change the PCB board
Defrost	Defrosting indicate	☆☆☆☆☆☆☆☆(all long flashes)		
Communication failure	E8	Bright		

MAINTENANCE

Maintenance activities

In order to ensure an optimum operation of the unit, a number of checks and inspections on the unit and the field wiring have to be carried out at regular intervals, preferably yearly.

- > Check the water supply and air vent frequently, to avoid lack of water or air in the water loop.
- Clean the water filter to keep a good water quality. Lack of water and dirty water can damage the unit.
- Keep the unit in a place where it is dry and clean, and which has good ventilation. Clean the heat exchanger every one to two months.
- Check each part of the unit and the pressure of the system. Replace the defect part if there is any, and recharge the refrigerant if it is required.
- Check the power supply and the electrical system, make sure the electrical components are good, and the wiring is well. If there is a damaged part or a strange smell, please replace it in time.
- If the heat pump is not used for a long time, please drain out all the water from the unit and seal the unit to keep it good. Please drain the water from the lowest point of the boiler to avoid freezing in winter. Water recharge and full inspection on the heat pump is required before it is restarted.
- Do not turn the power 'OFF' when you use the unit continuously, or the water in the pipe will freeze and split the pipe.
- > Keep the unit clean by means of soft damp cloth, no maintenance is required by the operator.
- > It is recommended to clean the tank and e-heater regularly to keep an efficient performance.
- It is recommended to set a lower temperature to decrease the heat release, prevent scale and save energy if the outlet water is sufficient.
- > Clean the air filter regularly to keep an efficient performance.

TROUBLESHOOTING

This section provides useful information for diagnosing and correcting certain troubles which may occur. Before starting the troubleshooting procedure, carry out a thorough visual inspection of the unit and look for obvious defects such as loose connections or defective wiring.

Before contacting your local dealer, read this chapter carefully, it will save you time and money.



WHEN CARRYING OUT AN INSPECTION ON THE SWITCH BOX OF THE UNIT, ALWAYS MAKE SURE THAT THE MAIN SWITCH OF THE UNIT IS SWITCHED 'OFF'.

The guidelines below might help to solve your problem. If you cannot solve the problem, consult your installer/local dealer.

- > No image on the controller (blank display). Check if the main power is still connected.
- > One of the error codes appears, consult your local dealer.
- The scheduled timer does work but the programmed actions are executed at the wrong time (e.g. 1 hour too late or too early). Check if the clock and the day of the week are set correctly, adjust if necessary.

ENVIRONMENTAL INFORMATION

This equipment contains fluorinated greenhouse gases covered by the Kyoto Protocol. It should only be serviced or dismantled by professional trained personnel.

This equipment contains R134a refrigerant in the amount as stated in the specification. Do not vent R134a into the atmosphere: R134a, is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 1430.

DISPOSAL REQUIREMENTS

Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.



Your product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and other parts must be done by a qualified installer in accordance with relevant local and national legislation.


Units must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring that this product is disposed off correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

WIRING DIAGRAM

Please refer to the wiring diagram on the electric box.


ATHW-20a/150L; ATHW-20a/200L; ATHW-20a/300L

With solar heat exchange coil




ATHW-20a/150LW; ATHW-20a/200LW; ATHW-20a/300LW

Without solar heat exchange coil




ATHW-40a/500L

With solar heat exchange coil



ATHW-40a/500LW

Without solar heat exchange coil



TECHNICAL SPECIFICATION

		<u> </u>		1					
TECHNICAL DAT	A	150LW	150L	200LW	200L	300LW	300L	500LW	500L
Power supply	V/Ph/Hz			_	220~2	240/1/50			
Water tank Volume	L	1	50	20	00	3	00	5	00
Max power input	W	700 + 1600 1420+16 (e-heater) (e-heater)							
Max current	A	3.2+ 6.8 (e-heater) 6.2+6.8 (heater)						•	
Max.outlet water temperature range(without using E-heater)	°C	60							
Max. water temperature	°C					70			
Min. water temperature	°C					1			
Ambient working temp.	°C				-5	ō~43			
Max. discharge pressure	bar					20			
Min. suction pressure	6								
Refrigerant type		R134a							
	Туре	Rotary							
	Brand	GMCC							
Compressor	Model	PJ125G1C-4DZDE					0M2C- FT		
	Туре	Asynchronous motor							
	W	80					6	60	
Fan motor	RPM			12	280			11	30
Air flow	m³ /h			4	50			4	00
Duct diameter	mm			177 (Fit	flexible	180/200	mm duc	:t)	
Max allowed pressure of tank	bar					10			
Inside body material of tank					SU	S 304			
Auxiliary electrical heater	kW	1.6 (incoloy825)							
Electronic expansion valve		yes							
The electronic anode		yes							
Solar heat exchanger		SUS316 SUS316 SUS316 SUS316 SUS31						SUS316 ~ 1 m²	
Hot water outlet	inch	G3/4 G 1							
Solar heat source inlet/outlet	inch	G 3/4							

Cold water inlet	inch	G 3/4	G 1		
Drainage	inch	G 3 / 4			
Condensed water outlet	inch	G 1 / 2			
Heat pump heat exchanger material		Aluminium alloy			

Net Dimensions	mm	Ф560x1500	Ф560x1750	Ф640x1845	Ф700x2250
Packing Dimensions	mm	629x629x1635	629x629x1892	695x695x1989	755x755x2370
Net Weight	kg	86	90	101	122
Gross Weight	kg	90	100	110	132
Sound power level	dB (A)	6	0	59	59.8

NOTES: * During disinfection, the max water temp could be up to 70°C by electrical heater

TEMPERATURE SENSOR R-T CONVERSION TABLE

R 25=	5.0KΩ±1.	0%

B25-50 = 3470K±1.0%

°C	Rmin /KΩ	ΚΩ	Rmax/ KΩ	°C	Rmin	κΩ	Rmax/	°C	Rmin /KΩ	ΚΩ	Rmax/
					/ΚΩ		κΩ				κΩ
-20	36.195	37.303	38.441	21	5.779	5.847	5.914	62	1.343	1.374	1.406
-19	34.402	35.437	36.499	22	5.558	5.62	5.683	63	1.301	1.331	1.362
-18	32.709	33.676	34.668	23	5.346	5.404	5.463	64	1.26	1.29	1.321
-17	31.109	32.012	32.939	24	5.144	5.198	5.252	65	1.221	1.25	1.28
-16	29.597	30.441	31.306	25	4.95	5	5.05	66	1.183	1.212	1.242
-15	28.168	28.957	29.765	26	4.761	4.811	4.861	67	1.147	1.175	1.204
-14	26.816	27.554	28.308	27	4.58	4.63	4.68	68	1.111	1.139	1.168
-13	25.538	26.227	26.932	28	4.408	4.457	4.507	69	1.077	1.105	1.133
-12	24.328	24.972	25.631	29	4.242	4.292	4.341	70	1.045	1.072	1.099
-11	23.183	23.785	24.4	30	4.084	4.133	4.182	71	1.013	1.04	1.067
-10	22.098	22.661	23.236	31	3.933	3.981	4.03	72	0.983	1.009	1.035
-9	21.071	21.598	22.135	32	3.788	3.836	3.885	73	0.953	0.979	1.005
-8	20.098	20.59	21.093	33	3.649	3.697	3.745	74	0.925	0.95	0.975
-7	19.176	19.636	20.106	34	3.516	3.563	3.611	75	0.897	0.922	0.947
-6	18.301	18.732	19.171	35	3.388	3.435	3.483	76	0.871	0.895	0.919
-5	17.472	17.875	18.285	36	3.266	3.313	3.36	77	0.845	0.869	0.893
-4	16.686	17.063	17.446	37	3.149	3.195	3.241	78	0.82	0.843	0.867
-3	15.94	16.292	16.65	38	3.037	3.082	3.128	79	0.796	0.819	0.842
-2	15.231	15.561	15.896	39	2.929	2.974	3.019	80	0.773	0.795	0.818
-1	14.559	14.867	15.18	40	2.826	2.87	2.915	81	0.751	0.773	0.795
0	13.92	14.208	14.501	41	2.726	2.77	2.815	82	0.729	0.751	0.773
1	13.313	13.582	13.856	42	2.631	2.675	2.718	83	0.708	0.729	0.751
2	12.736	12.988	13.244	43	2.54	2.583	2.626	84	0.688	0.709	0.73
3	12.188	12.423	12.662	44	2.452	2.494	2.537	85	0.668	0.689	0.709
4	11.666	11.887	12.11	45	2.368	2.409	2.451	86	0.649	0.669	0.69
5	11.17	11.376	11.585	46	2.287	2.328	2.369	87	0.631	0.651	0.671
6	10.698	10.891	11.086	47	2.209	2.25	2.29	88	0.613	0.632	0.652
7	10.249	10.429	10.611	48	2.135	2.174	2.214	89	0.596	0.615	0.634
8	9.822	9.99	10.16	49	2.063	2.102	2.141	90	0.579	0.598	0.617
9	9.414	9.572	9.73	50	1.994	2.032	2.071	91	0.563	0.581	0.6
10	9.027	9.173	9.321	51	1.927	1.965	2.003	92	0.548	0.566	0.584
11	8.657	8.794	8.932	52	1.863	1.901	1.938	93	0.533	0.55	0.568
12	8.305	8.432	8.561	53	1.802	1.839	1.876	94	0.518	0.535	0.553
13	7.969	8.088	8.208	54	1.743	1.779	1.815	95	0.504	0.521	0.538
14	7.648	7.76	7.872	55	1.686	1.721	1.757	96	0.49	0.507	0.524
15	7.343	7.446	7.551	56	1.631	1.666	1.701	97	0.477	0.493	0.51
16	7.051	7.148	7.245	57	1.579	1.613	1.647	98	0.464	0.48	0.496
17	6.773	6.863	6.953	58	1.528	1.561	1.595	99	0.452	0.467	0.483
18	6.507	6.5911	6.675	59	1.479	1.512	1.545	100	0.439	0.455	0.47
19	6.253	6.331	6.41	60	1.432	1.464	1.497				
20	6.011	6.083	6.156	61	1.386	1.418	1.451				

TEMPERATURE SENSOR R-T CONVERSION TABLE Only use for the solar temp sensor

R25=50KΩ±1.0% B25/50 = 3950K±1.0%									
°C	R(cent)	°C	R(cent)	°C	R(cent)	°C	R(cent)		
-20	466.6	15	78.38	50	17.93	85	5.227		
-19	441.1	16	74.85	51	17.26	86	5.061		
-18	417.2	17	71.5	52	16.61	87	4.902		
-17	394.7	18	68.32	53	15.99	88	4.748		
-16	373.5	19	65.29	54	15.4	89	4.6		
-15	353.6	20	62.41	55	14.83	90	4.457		
-14	334.8	21	59.68	56	14.29	91	4.319		
-13	317.2	22	57.07	57	13.77	92	4.188		
-12	300.6	23	54.6	58	13.27	93	4.058		
-11	284.9	24	52.24	59	12.79	94	3.935		
-10	270.2	25	50	60	12.33	95	3.815		
-9	256.3	26	47.86	61	11.89	96	3.7		
-8	243.1	27	45.83	62	11.46	97	3.589		
-7	230.7	28	43.89	63	11.06	98	3.482		
-6	219	29	42.05	64	10.67	99	3.378		
-5	208	30	40.28	65	10.29	100	3.278		
-4	197.6	31	38.61	66	9.936	101	3.182		
-3	187.7	32	37.01	67	9.591	102	3.088		
-2	178.4	33	35.49	68	9.259	103	2.998		
-1	169.6	34	34.03	69	8.941	104	2.911		
0	161.3	35	32.65	70	8.635	105	2.827		
1	153.4	36	31.32	71	8.341	106	2.746		
2	146	37	30.06	72	8.058	107	2.667		
3	139	38	28.85	73	7.786	108	2.591		
4	132.3	39	27.7	74	7.525	109	2.517		
5	126	40	26.6	75	7.247	110	2.446		
6	120	41	25.55	76	7.032	111	2.378		
7	114.3	42	24.54	77	6.8	112	2.311		
8	109	43	23.58	78	6.576	113	2.247		
9	103.9	44	22.66	79	6.361	114	2.184		
10	99.04	45	21.78	80	6.153	115	2.124		
11	94.47	46	20.94	81	5.954	116	2.065		
12	90.12	47	20.14	82	5.762	117	2.009		
13	86	48	19.37	83	5.577	118	1.955		
14	82.09	49	18.64	84	5.398	119	1.902		

作图日期2024.04.23

902000100092

SMS-ATLAS-KT-20/EN3L300-02

本文件黑白印刷,尾页增加1张空白页。

注:本文件大部分内容版本以8802000101696 SMS-ZX-KT-20/EN3L300-1[B] 为基准作图,故障代码P7、P8部分按旧版。

注意:本页不用印刷,仅对印刷颜色做要求。