


Wave-Inverter Swimming Pool Heat Pump

-Installation and Operation Manual-



THANK YOU

Dear Customer,

Thank you for choosing our products and greatly we appreciate your confidence in us!

These are the **Wave-Inverter** Swimming Pool Heat Pumps for heating or cooling your pool and extending your swimming season. This is a special Pool heat pumps which is most close to users and why? It is a smart heat pump who knows how to heat your pool most efficiently and maintain pool temperature, thanks to the full inverter technology. Our target is to provide you with an exceptional high performance quality product.

We have produced this manual with the utmost care so that you get maximum benefit from your heat pump.



Please read carefully

TABLE OF CONTENT

INTRODUCTION	2
This manual	2
The unit	2
SAFETY INSTRUCTIONS	3
ITEMS INSIDE PRODUCT BOX	5
OVERVIEW OF THE UNIT	6
Unit Dimension	6
Explode View	7
INSTALLATION	8
Installation information	8
Condition of installation	8
Installation place	8
To perfect your installation	8
Water connection	8
Electrical connection	10
Trial running	11
OPERATING THE UNIT	12
Controller Instruction	12
Display Instruction	12
PARAMETER CHECKING AND ADJUSTMENT	15
Parameter list	15
Malfunctioning of the unit and maintenance	15
MAINTENANCE THE UNIT	18
Cleaning the pipe system in the heat exchanger	18
Cleaning the air system	18
Winter Shutdown/Lay-up	18
TROUBLESHOOTING	18
ENVIRONMENTAL INFORMATION	19
DISPOSAL REQUIREMENTS	19
WIRING DIAGRAM	20
Specification	24
ENVIRONMENTAL INFORMATION	27
DISPOSAL REQUIREMENTS	27



READ THIS MANUAL CAREFULLY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY. KEEP IT IN YOUR FILES FOR FUTURE REFERENCE.



BEFORE OPERATING THE UNIT, MAKE SURE THE INSTALLATION HAS BEEN CARRIED OUT CORRECTLY BY A PROFESSIONAL DEALER. IF YOU FEEL UNSURE ABOUT OPERATION, CONTACT YOUR DEALER FOR ADVICE AND INFORMATION.

INTRODUCTION

This manual

This manual includes the necessary information about the unit. Please read this manual carefully before you use and maintain the unit.

The unit

The swimming pool heat pump is one of the most economical systems to heat the swimming pool efficiently. Using the free renewable energy from the air and the earth it delivers up to five times more energy in heating than a traditional heating system such as gas boiler or electric heater. So you will save 4/5 cost of the traditional heating. The swimming pool heat pump lengthens your swimming season and gives you comfort at high level. You could enjoy swimming not only in summer, but also in spring, autumn and even winter time.

✧ **Ecological and economical heating**

By making use of the renewable energy in the outside air, it consumes much less energy with low carbon emission. Use environment friendly advanced refrigerant R32 which has no effect on Ozone.

✧ **Titanium heat exchanger**

Advanced titanium heat exchanger guarantees long life span of heat pump free from corrosion and rust. By using of titanium heat exchanger the heat pump could be applied with all types of water treatment such as chlorinate, iodine, bromine and salt water.

✧ **Multiple functions**

- Cooling and heating ,Auto functions available;
- Auto operation, Auto-restart, Auto defrost
- Timer on/off: no human attendance is required
- Wide ambient working condition: -15°C to 43°C

✧ **Reliable operation**

To guarantee the stable running and increase the stability of the unit multiple protection devices have been set into pool heat pump which includes insufficient water flow protection, high/low pressure protection, overload protection, compressor protection.

✧ **Safe use**

The swimming pool heat pump works without oil, gas or other hazardous substance which avoid potential risk that goes together. Moreover no gas connection or a fuel tank is needed. No risk of intoxication, smell or pollution from leakage.

✧ **Self-diagnosis**

When there is malfunction, the swimming pool heat pump will make self-diagnosis by displaying error code from the control panel. The problem could be found out at a glance.

SAFETY INSTRUCTIONS

To prevent injury to the user, other people, or property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage.

Install the unit only when it complies with local regulations, by-laws and standards. Check the main voltage and frequency. This unit is only suitable for earthed sockets, connection voltage 220 – 240 V ~ / 50Hz.

The following safety precautions should always be taken into account:

- Be sure to read the following WARNING before installing the unit.
- Be sure to observe the cautions specified here as they include important items related to safety.
- After reading these instructions, be sure to keep it in a handy place for future reference.



Do not install the unit yourself.

Incorrect installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or a specialized installer.

Install the unit securely in a place.

When insufficiently installed, the unit could fall causing injury. When installing the unit in a small room, please take measures (like sufficient ventilation) to prevent the asphyxia caused by the leakage of refrigerant.

Use the specified electrical wires and attach the wires firmly to the terminal board (connection in such a way that the stress of the wires is not applied to the sections).

Incorrect connection and fixing could cause a fire.

Be sure to use the provided or specified parts for the installation work.

The use of defective parts could cause an injury due to possible fire, electric shocks, the unit falling etc.

Perform the installation securely and please refer to the installation instructions.

Incorrect installation could cause an injury due to possible fire, electric shocks, the unit falling, leakage of water etc.

Perform electrical work according to the installation manual and be sure to use a dedicated section. If the capacity of the power circuit is insufficient or there is an incomplete electrical circuit, it could result in a fire or an electric shock.

The unit must always have an earthed connection.

If the power supply is not earthed, you may not connect the unit.

Never use an extension cable to connect the unit to the electric power supply.

If there is no suitable, earthed wall socket available, have one installed by a recognized electrician.

Do not move/repair the unit yourself.

Before proceeding with any maintenance, service or repair work, the product must be isolated from the mains electrical supply. Only qualified personnel should carry out these tasks. Improper movement or repair on the unit could lead to water leakage, electrical shock, injury or fire.



CAUTION

Do not install the unit in a place where there is a chance of flammable gas leaks.

If there is a gas leak and gas accumulates in the area surrounding the unit, it could cause an explosion.

Perform the drainage/piping work according to the installation instruction.

If there is a defect in the drainage/piping work, water could leak from the unit and household goods could get wet and be damaged.

Do not clean the unit when the power is 'ON'.

Always shut 'OFF' the power when cleaning or servicing the unit. If not, it could cause an injury due to the high speed running fan or an electrical shock.

Do not continue to run the unit when there is something wrong or there is a strange smell.








The power supply needs to be shut 'OFF' to stop the unit; otherwise this may cause an electrical shock or fire.

Do not put your fingers or others into the fan, or evaporator.

The ventilator runs at high speed, it could cause serious injury.


ITEMS INSIDE PRODUCT BOX

Before starting the installation, please make sure that all parts are found inside the box.

The Unit Box		
Item	Image	Quantity
Wave-Inverter Swimming pool heat pump		1
Installation and Operation Manual		1
Extension cable 15m Cable		1
Water Connectors (55mm)		2
Winter Cover		1
Rubber foots for anti-vibration		4
Water Drainage Pipe		1

OVERVIEW OF THE UNIT


Unit Dimension



Dimension: mm

MODEL	NBSP005/07/09N8	NBSP011/14/17N8	NBSP021/23/ 25N8/25N8T	NBSP029/32N8 /29N8T/32N8T
A	860	986	1076	1176
B	668	668	720	822
C	331	356	426	451
D	380	405	456	481
E	600	608	628	723
F	106	106	116	116
G	350	380	330	500
H	128	189	219	219
I	118	123	158	163

Explode View



No.	Name	No.	Name
1	Top Cover	15	Bottom Panel component
2	Electric box cover	16	Inverter compressor
3	Support frame	17	High-pressure valve
4	Electronic control components	18	Low-pressure switch
5	Fin heat exchanger	19	Power waterproof cover
6	Left panel	20	Needle valve
7	Motor bracket	21	Controller
8	DC fan motor	22	Four-way valve
9	Middle panel	23	Water flow switch
10	Fan	24	Right panel
11	Front Panel	25	Titanium tube heat exchanger
12	Discharge grill	26	High pressure gauge
13	Reactance waterproof box	27	Electronic expansion valve
14	Reactance		

INSTALLATION

Installation information

The following information given here is not an instruction, but simply meant to give the user a better understanding of the installation.

Condition of installation

The following information given here is not an instruction, but simply meant to give the user a better understanding of the installation.

Installation place

Install the swimming pool heat pump on a flat, horizontal, and stable surface. Maintain 1 M of open space in front of the discharge grids and 3 M on the outlet side of the ventilator. And reserve enough space to allow access to temperature controller.

Make sure that the discharged air will not be breathed in.

The heat pump must be installed with anti-vibration pads on its feet and secured using bolts (anti-vibration pads are included in the accessory kit).

To perfect your installation

- Avoid directing the flow of ventilated air towards a sensitive noise zone, such as room window.
- Avoid positioning pool heat pump on a surface that can transmit vibrations to dwelling.
- Try to avoid placing appliance under a tree or exposed to water or mud, which would be likely to complicate maintenance.


Water connection

When installing water pipes on the heat pump side, flexible hoses should be used for connection and fixation, requiring a minimum length of 500mm.

The heat pump is connected to a filtration circuit with a by-pass.

It is imperative that the by-pass is placed after the pump and the filter. The by-pass generally consists of 3 valves.

This makes it possible to regulate the water flow which passes through the heat pump and to isolate the heat pump completely for any maintenance work, without cutting the flow of filtered water.



During the first months of use, your heat pump is subject to condensation. This will result in water flows, more or less important depending on the moisture content, which will gradually diminish.

To channel condensation flows, we recommend that you install our condensate drain kit. For this purpose the heat pump must be raised by at least 10 cm.

The heat pump must be installed with anti-vibration pads on its feet and secured using bolts (anti-vibration pads are included in the accessory kit).

How to install the condensate drain kit?

1. Install your heat pump by raising it by at least 10 cm using solid, moisture-resistant studs.
2. Connect the exhaust hose to the drain hole located underneath the heat pump.


Hydraulic Connection

CAUTION A "By-Pass Ø50" kit is essential for the installation of your heat pump. It is a kit usually consisting of 3 valves, 2 T, 2 elbows of diameter 50 mm, 1 stripper and 1 glue.




We recommend that you only half open your intermediate valve to avoid excessive pressure on your heat pump (see diagram).


If your setting is correct, the pressure gauge of your heat pump will be in working order.



SINGLE INSTALLATION DIAGRAM



SERIAL INSTALLATION DIAGRAM



The filter must be cleaned regularly to ensure that the water in the system is clean and to avoid any problems related to dirt or clogging of the filter.

Electrical connection

Electrical supply must correspond to that indicated on the appliance.

Connection cables have to be sized according to appliance power and installation requirements. Please refer to below table:

Heat pump	Cable size
NBSP005N8	3x1.5mm ² /AWG 16
NBSP007N8	3x2.5mm ² /AWG 14
NBSP009N8	3x2.5mm ² /AWG 14
NBSP011N8	3x2.5mm ² /AWG 14
NBSP014N8	3x2.5mm ² /AWG 14
NBSP017N8	3x4.0mm ² /AWG 12
NBSP021N8	3x4.0mm ² /AWG 12
NBSP023N8	3x6.0mm ² /AWG 10
NBSP025N8	3x6.0mm ² /AWG 10
NBSP025N8T	5x4.0mm ² /AWG 12
NBSP029N8	3x10mm ² /AWG 8
NBSP032N8	3x10mm ² /AWG 8
NBSP029N8T	5x4.0mm ² /AWG 12
NBSP032N8T	5x4.0mm ² /AWG 12

These data are only indication, you must ask an electrician to determine the exact data for your pool installation.
Use the cable glands and grommets provided inside the heat pump to route cables.

If the length of your cable is more than 10 meters, we advise you to seek advice from a professional.
A voltage variation of $\pm 10\%$ during operation is acceptable.
The power supply lines must be securely fastened.
The cable must be suitable for outdoor use.

- Step 1 :** Dismantle the side electrical panel with a turn-Nevis to access the electrical terminal block.
Step 2 : Insert the cable into the heat pump unit in Passing through the opening provided for this purpose.
Step 3 : Attach the cable to the terminal according to EN (single-Phased) or A / B / C / N (three-phase).
Step 4 : Close the heat pump panel carefully by replacing the screws.
Step 5 : Properly connect the signal cable terminals to the central control box.

Trial running

After connecting water to the pool system, complete with a suitable by-pass and electrical connections by a qualified engineer.

Be sure that:

- 1) Appliance is horizontal and on a firm base.
- 2) Water circuit is well connected (no leaks and no chance of injury due to badly fitted hydraulic couplings).
- 3) Electrical circuit is well connected (all cables tightened correctly at terminals and intermediate circuit breaker), insulated and earthed correctly.
- 4) The installation requirements described previously are strictly adhered to.






ATTENTION: THE HEAT PUMP ONLY FUNCTIONS WHEN WATER FLOW IS PRESENT.

Then you can start up the heat pump following every point in the below order:

- Open by-pass valves
- Start pool system pump
- Turn on pool heat pump
- Set regulation

OPERATING THE UNIT

Operating the unit comes down to operating the digital controller.

-  NEVER LET THE DIGITAL CONTROLLER GET WET. THIS MAY CAUSE AN ELECTRIC SHOCK OR FIRE.
-  NEVER PRESS THE BUTTONS OF THE DIGITAL CONTROLLER WITH A HARD, POINTED OBJECT. THIS MAY DAMAGE THE DIGITAL CONTROLLER.
-  NEVER INSPECT OR SERVICE THE DIGITAL CONTROLLER YOURSELF, ASK A QUALIFIED SERVICE PERSON TO DO THIS.


Controller Instruction

General

Input Voltage: DC12V RS485 Communication

Operation temperature range for controller is -30~70℃.

Display Instruction





Temperature :

Press Sun/ Snowflake/ Logo "A" and select the desired mode again (Sun= hot mode; Snowflake= cold mode; Logo A= automatic mode).

Use the arrows to indicate the temperature to increase or decrease the desired temperature



Temperature :

According to the figure below, the current temperature in the pool is 15 degrees, and the set temperature is 33 degrees.



Operation type :

Click the hexagon to select a different operation type.

Boost : Best performance.

Smart : Economy / intelligence.

Silence : Slow ventilation and stable performance.



Parameters / Alarms :

Click hexagon to enter the parameter menu.

Parameter queries allow different parameters to be read without modifying them.



Parameters / Alarms (2):

⚠ Parameter setting: strictly for technicians entrusted by the factory. The password will not be passed.

Time setting: it is allowed to set the operating time range to allow the heat pump to operate as required.

Fault history: allows you to access the fault history, which contains the error code and the time when the fault occurred.

In this example, the fault corresponds to error code P01.



Standby button :

The small button in the upper right corner of the screen can turn on or off the sleep mode of the screen.



Attention :

The on/off button at the upper right corner of the screen allows or does not allow the heat pump to operate.

Example: if the slider in the upper right corner is in the stop position, the heat pump will not start.



PARAMETER CHECKING AND ADJUSTMENT

Parameter list

Some parameters can be checked and adjusted by the controller. Below is the parameter list.

No.	Name	Instruction
1	Compressor running Frequency	Current frequency
2	EEV Open degree	Current Value/ 5
3	Ambient Temperature	Current °C
4	Outlet Water Temp.	Current °C
5	Exhaust gas Temp.	Current °C
6	Return gas Temp.	Current °C
7	Coil Temp.	Current °C
8	4-way Valve outlet Temp.	Current °C
9	Water Circulation Pump	0-off; 1-on
10	4-way Valve Status	0-off; 1-on
11	Standby	/
12	Standby	/
13	Standby	/
14	Standby	/
15	Standby	/
16	Running Current of Compressor	Current*10
17	Voltage	Current/10
18	Standby	/
19	Standby	/
20	Standby	/
21	Fan speed	Current/10

Malfunctioning of the unit and maintenance

When an error occurs or the protection mode is set automatically, the circuit board and the wired controller will both display the error message. (About "too high protection of hot water temperature" \leq 25kW swimming pool heat pump fault code is "P12", >25kW swimming pool heat pump fault code is "P14".)

Error	Meaning	Analysis	Diagnosis	Solution
P01	Water Flow failure	1. No water flow; 2. Flow switch failure; 3. Water system block.	1. Check if water in valve is closed or no water in; 2. Check if flow switch is blocked or damaged; 3. Check if "Y" Shape filter blocked.	1. Open the valve; 2. Change a new flow switch ; 3. Clean or change a new filter.
P02	High pressure protection	1. Water flow is too small ; 2. High-pressure switch is damaged; 3. Refrigerant system block; 4. EEV deadlock.	1. Check if water flow is not enough or water pump flow is not enough; 2. Check if high-pressure switch is off; 3. Check if refrigerant system is blocked; 4. When heat pump is off and turn the heat pump on and off to check if EEV can be listened by sound of reset.	1. Reinject water or change to a new pump of larger water flow; 2. Change a new high-pressure switch; 3. Change a new filter 4.Change a new EEV.

P03	Low pressure protection	1. Lack of gas ; 2. Refrigerant system block; 3. Exceed heat pump operation range.	1. Check if gas system is leaking; 2. Check if filter is blocked; 3. Check ambient Temp. And water temp.is over limitation.	1. Amend theleakage and reinject the gas; 2. Change a new filter.
P04	T3 Coil overheat protection	1. Heat Pump fan blowing area is blocked; 2. Evaporator is blocked; 3. T3 coil sensor position was changed.	1. Check if the blowing area is open; 2. Check if the evaporator is blocked; 3. Check if the coil sensor resistance value is correct.	1. Put away the blow area; 2. Clean the evaporator; 3. Change a new sensor.
P05	Exhausting gas temperature protection	1. Lack of gas; 2. Sensor position was changed.	1. Check if refrigerant system is leaking; 2. Check if the sensor resistance value is correct.	1. Amend the leakage and reinject the gas; 2. Change a new sensor.
P06	Outlet water temperature anti-freezing protection	1. Lower water flow; 1. Heat exchanger blocked; 2. Y-shaped filter blocked; 3. Over low load.	1. Check if air exists in water system; 2. Plate heat exchanger if blocked; 3. Check if Y-shaped filter has block; 4. Check design of indoor water system if reasonable, if have water bypass.	1. If drain valve has problem, change a new one; 2. Blow plate heat exchanger with water or high-pressure gas through reverse direction; 3. Clean Y-shaped filter; 4. Water system must have bypass.
P07	Pipe temperature anti-freezing protection	1. System lack of gas; 2. Water system has block; 3. Cooling system has block.	1. Check system if any leakage; 2. Check Y-shaped filter has block; 3. Check if cooling system filter has block.	1. Fix leakage and re-charge gas; 1. Clean Y-shaped filter; 2. Change filter.
P08	High-pressure 2 protection	High pressure switch 2 cuts	Check if high pressure switch 2 cuts under unit OFF condition	Change high pressure switch 2
P11	DC fan fault	1. The fan is faulty or stuck. 2. The main control board is faulty	1. Check whether the fan is stuck, or replace with a new fan. 2. Replace the main control board	1. Check if the fan is stuck, or replace with a new fan. 2. Replace the main control board.
P12/ P14	High temperature protection of heating water outlet	1. Too low water flow 2. Main PCB damaged	1. Check if water in valve is closed or no water in; 2. Check if flow switch is blocked or damaged; 3. Check if "Y" Shape filter blocked.	1. Check the water filter and water circuit (no block) 2. Replace the PCB
E01	Controller communication failure	Communication cable cuts	Check communication cable if cut	Change connection cable or re-connect
E02	TP1 exhaust gas temperature sensor failure	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable
E03	T3 coil temperature sensor failure	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable
E04	T4 ambient temperature sensor failure	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable
E05	T5 liquid gas temperature sensor	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable
E06	TH return gas temperature sensor failure	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable
E07	TW water tank temperature sensor failure	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable

E08	TA inlet water temperature sensor failure	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable
E09	TB outlet water temperature sensor failure	Sensor temperature deviation or cuts	Check sensor resistance value or if sensor cuts	Change sensor or re-connect cable
E10	Controller and Drive PCB Communicate failure	Communication cable cuts	Check communication cable if cut	Change connection cable or re-connect
E11	Reserved	<p>Wiring error or IPM module invalid Check if wiring error Re-connect cable or change IPM module</p>		
E12	Reserved			
E13	Reserved			
E14	Reserved			
E15	DC main cable voltage too low			
E16	DC main cable voltage too high			
E17	AC current protection (input side)			
E18	IPM module abnormality			
E19	PFC abnormality			
E20	Compressor start failure			
E21	Compressor lack-phase			
E22	IPM module reset			
E23	Compressor over-current			
E24	PFC module extra high temperature			
E25	Current detection Circuit failure			
E26	out of step			
E27	PFC module temperature sensor abnormality			
E28	communication failure			
E29	IPM module extra high temperature			
E30	IPM module temperature sensor failure			
E31	reserved			
E32	IPM adjustment data			
E33	IPM adjustment data			
E34	AC input voltage abnormality			
E35	IPM adjustment data			
E36	Reserved			
E37	IPM module current frequency limits			
E38	IPM module voltage frequency limits			
E51	Failure of Fan motor drive			

MAINTENANCE THE UNIT

To protect the paintwork, avoid leaning or putting objects on the device. External heat pump parts can be wiped with a damp cloth and domestic cleaner. (Attention: Never use cleaning agents containing sand, soda, acid or chloride as these can damage the surfaces.)

To prevent faults due to sediments in the titanium heat exchanger of the heat pump, ensure that the heat exchanger cannot be contaminated (water treatment and filter system necessary). In the event that operating malfunctions due to contamination still occur, the system should be cleaned as described below. (Warning: the fins on the finned tube heat exchanger are sharp-edged -- danger of being cut!)

Cleaning the pipe system in the heat exchanger

Contamination in the pipes and heat exchanger can reduce the performance of the heat pump's titanium heat exchanger. If this is the case, the pipe system and heat exchanger must be cleaned by a technician. Use only pressurized drinking water for cleaning.

Cleaning the air system

The finned heat exchanger, ventilator and condensate outflow should be cleaned of contaminants (leaves, twigs, etc.) before each new heating period. These types of contaminants can be manually removed using compressed air or by flushing with clean water.

It may be necessary to remove the device cover and air inlet grid first.

Attention: Before opening the device, ensure that all circuits are isolated from the power supply.

To prevent the evaporator and the condensate tray from being damaged, do not use hard or sharp objects for cleaning.

Under extreme weather conditions (e.g. snow drifts), ice may form on the air intake and exhaust air outlet grids. If this happens, the ice must be removed in the vicinity of the air intake and exhaust air outlet grids to ensure that the minimum air flow rate is maintained.

Winter Shutdown/Lay-up

If there is a chance of frost after the bathing-season has ended when the swimming pool heating is switched off and the external temperature is expected to drop below the operating limit, the water circuit of the heat pump should be completely drained. Otherwise, suitable constructional measures should be taken by the customer to protect the heat pump against damage from frost.

Attention: The warranty does not cover damage caused by inadequate lay-up measures during the winter.

TROUBLESHOOTING

This section provides useful information for diagnosing and correcting certain troubles which may occur. Before starting the troubleshooting procedure, carry out a thorough visual inspection of the unit and look for obvious defects such as loose connections or defective wiring.

Before contacting your local dealer, read this chapter carefully, it will save you time and money.



WHEN CARRYING OUT AN INSPECTION ON THE SWITCH BOX OF THE UNIT, ALWAYS MAKE SURE THAT THE MAIN SWITCH OF THE UNIT IS SWITCHED 'OFF'.

The guidelines below might help to solve your problem. If you cannot solve the problem, consult your installer/local dealer.

The heat pump will not run.

Please check whether:

- There is supply voltage (tripped fuse, power failure).
- The operating switch on the wired controller is switched on, and whether the correct set point temperature has been set.

The set temperature level cannot be reached. Please check whether:

- The permissible operating conditions for the heat pump have been adhered to (air temperatures too high or too low).
- The air inlet or outlet area is blocked, restricted or very dirty.
- There are closed valves or stop-cocks in the water pipes.

The scheduled timer does work but the programmed actions are executed at the wrong time (e.g. 1 hour too late or too early).

Please check whether:

- The clock and the day of the week are set correctly, adjust if necessary.

If you cannot correct the fault yourself, please contact your after-sales service technician. Work on the heat pump may only be carried out by authorized and qualified after-sales service technicians.

ENVIRONMENTAL INFORMATION

This equipment contains fluorinated greenhouse gases covered by the Kyoto Protocol. It should only be serviced or dismantled by professional trained personnel.

This equipment contains R32 (formula: CH_2F_2) refrigerant in the amount as stated in the specification. Do not vent R32 into the atmosphere: R32 is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 675.

DISPOSAL REQUIREMENTS

Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.



Your product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.


Do not try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and other parts must be done by a qualified installer in accordance with relevant local and national legislation.


Units must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring that this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information


WIRING DIAGRAM


Please refer to the wiring diagram on the electric box. Model:

Model: NBSP005/ 07/ 09/ 11/ 14N8









Specification

Host model	External model	NBSP005N8	NBSP007N8	NBSP009N8	NBSP011N8	NBSP014N8
Air15℃/Water26℃ Humidity 70%	Capacity(kW)	1.1~3.8	1.3~5.1	1.6~6.7	2.18~8.13	2.86~10.65
	Power input(kW)	0.14~0.75	0.17~1.06	0.21~1.34	0.28~1.59	0.38~2.17
	COP	5.1~7.9	4.8~7.8	5~7.7	4.9~7.8	4.9~7.6
	Capacity(kW) Boost	3.8	5.1	5.95	8.13	10.65
	COP Boost	5.1	4.8	5.00	4.90	4.90
	Capacity(kW) Smart	3.04	4.08	4.76	6.50	8.52
	COP Smart	5.91	5.9	5.88	5.76	5.76
	Capacity(kW) Silent	2.01	2.55	2.98	4.07	5.33
	COP Silent	6.82	6.75	6.67	6.53	6.53
Air26℃/Water26℃ Humidity 80%	Capacity(kW)	1.6~5.3	1.6~7.2	1.9~9.2	2.7~10.9	3.4~14.3
	Power input(kW)	0.13~0.88	0.13~1.19	0.13~1.28	0.18~1.74	0.23~2.32
	COP	6.25~14.5	6.22~14.55	6.24~14.71	6.27~14.8	6.15~14.62
	Capacity(kW) Boost	5.3	7.2	9.20	10.90	14.30
	COP Boost	6.31	6.26	6.24	6.27	6.15
	Capacity(kW) Smart	4.4	5.92	7.45	8.94	11.44
	COP Smart	7.7	7.65	7.80	7.84	7.69
	Capacity(kW) Silent	2.8	3.7	4.60	5.45	7.15
	COP Silent	10.5	10.42	10.40	10.45	10.25
Air35℃/Water28℃ Humidity 80%	Capacity(kW)	1.5~2.8	1.7~3.6	1.8~4.6	2.4~6.0	3.2~7.87
	Power input(kW)	0.2~0.62	0.22~0.8	0.28~1.2	0.33~1.39	0.43~1.78
	EER	4.51~7.55	4.48~7.53	4.47~7.46	4.32~7.34	4.41~7.42
	Capacity(kW) Boost	2.8	3.6	4.60	6.00	7.87
	EER Boost	4.51	4.48	4.47	4.32	4.41
	Capacity(kW) Smart	2.24	2.88	3.68	4.80	6.30
	EER Smart	5.62	5.6	5.59	5.40	5.51
	Capacity(kW) Silent	1.7	2.16	2.30	3.00	3.94
	EER Silent	6.95	6.92	6.88	6.65	6.78
power supply	V / Ph / Hz	220-240~, 50/60				
max current	A	5.35	6.53	7.24	8.4	9.6
water flow	m³/h	2~3	3~4	3~5	4~6	5~7
Refrigerant volume		R32				
Min pressure/max pressure	MPa	1.5/4.15				
Operating air temperature	℃	-15~43				
compressor brand		GMCC				
compressor type		Rotary				
water proof level		IPX4				
package dimensions	L x W x H(mm)	860*331*668			986*356*668	
unit dimensions	L x W x H(mm)	950*410*800			1080*435*800	
noise at 1 m	dB(A)	35.3~43.1	37.7~46.1	38.1~47.2	38.3~48.1	38.5~48.6
noise at 10 m	dB(A)	19.1~27.2	19.5~27.4	20.5~27.9	20.6~28.2	20.8~28.6

Host model	External model	NBSP017N8	NBSP021N8	NBSP023N8	NBSP025N8
Air15℃/Water26℃ Humidity 70%	Capacity(kW)	3.49~13	3.76~15.7	4.64~17.34	5.15~18.52
	Power input(kW)	0.47~2.64	0.48~2.75	0.61~3.6	0.68~3.77
	COP	4.85~7.44	5.1~7.52	4.8~7.5	4.91~7.53
	Capacity(kW) Boost	13.00	15.70	17.34	18.52
	COP Boost	4.85	5.10	4.80	4.91
	Capacity(kW) Smart	10.40	12.56	13.87	14.82
	COP Smart	5.71	6.00	5.65	5.74
	Capacity(kW) Silent	6.50	7.85	8.67	9.26
	COP Silent	6.47	6.80	6.40	6.51
Air26℃/Water26℃ Humidity 80%	Capacity(kW)	4.3~17.4	4.8~21.2	5.7~23.2	6.2~25.1
	Power input(kW)	0.29~2.85	0.33~3.38	0.4~3.8	0.43~4.05
	COP	6.0~14.5	6.36~14.55	6.1~14.5	6.2~14.52
	Capacity(kW) Boost	17.40	21.20	23.20	25.10
	COP Boost	6.00	6.36	6.10	6.20
	Capacity(kW) Smart	14.01	17.17	18.79	20.10
	COP Smart	7.50	7.95	7.63	7.60
	Capacity(kW) Silent	8.70	10.60	11.60	12.52
	COP Silent	10.00	10.60	10.17	10.15
Air35℃/Water28℃ Humidity 80%	Capacity(kW)	3.9~9.6	4.3~11.5	5.3~12.8	5.8~13.9
	Power input(kW)	0.51~2.3	0.57~2.62	0.73~3.1	0.8~3.35
	EER	4.24~7.4	4.38~7.48	4.17~7.25	4.15~7.22
	Capacity(kW) Boost	9.60	11.5	12.80	13.90
	EER Boost	4.24	4.38	4.17	4.15
	Capacity(kW) Smart	7.68	9.20	10.24	11.10
	EER Smart	5.30	5.48	5.21	5.18
	Capacity(kW) Silent	4.80	5.75	6.40	6.95
	EER Silent	6.52	6.74	6.42	6.40
power supply	V / Ph / Hz	220-240~, 50/60			
max current	A	13.77	14.3	18.36	19.52
water flow	m³/h	6~8	7~9	8~10	8~11
Refrigerant volume		R32			
Min pressure/max pressure	MPa	1.5/4.15			
Operating air temperature	℃	-15~43			
compressor brand		GMCC			
compressor type		Rotary			
water proof level		IPX4			
package dimensions	L x W x H(mm)	986*356*668	1076*426*720		
unit dimensions	L x W x H(mm)	1080*435*800	1161*490*855		
noise at 1 m	dB(A)	41.5~52.5	42.3~53.1	44.2~54.5	44.7~54.9
noise at 10 m	dB(A)	23.0~31.8	23.6~32.2	24.3~33.4	24.6~33.7

Host model	External model	NBSP025N8T	NBSP029N8	NBSP032N8	NBSP029N8T	NBSP032N8T
Air15℃/Water26℃ Humidity 70%	Capacity(kW)	5.15~18.52	5.43~21.28	6.34~23.68	5.43~21.28	6.34~23.68
	Power input(kW)	0.68~3.77	0.73~4.3	0.87~4.8	0.73~4.3	0.87~4.8
	COP	4.91~7.53	4.95~7.51	4.9~7.6	4.95~7.51	4.9~7.6
	Capacity(kW) Boost	18.52	21.28	23.68	21.28	23.68
	COP Boost	4.91	4.95	4.9	4.95	4.9
	Capacity(kW) Smart	14.82	17.02	18.94	17.02	18.94
	COP Smart	5.74	5.82	5.76	5.82	5.76
	Capacity(kW) Silent	9.26	10.54	11.84	10.54	11.84
	COP Silent	6.51	6.60	6.53	6.60	6.53
Air26℃/Water26℃ Humidity 80%	Capacity(kW)	6.2~25.1	6.6~29.0	7.7~31.7	6.6~29.0	7.7~31.7
	Power input(kW)	0.43~4.05	0.46~4.75	0.54~5.21	0.46~4.75	0.54~5.21
	COP	6.2~14.52	6.1~14.54	6.11~14.6	6.1~14.54	6.11~14.6
	Capacity(kW) Boost	25.10	29.00	31.7	29.00	31.7
	COP Boost	6.20	6.10	6.11	6.10	6.11
	Capacity(kW) Smart	20.10	23.20	25.68	23.20	25.68
	COP Smart	7.60	7.63	7.64	7.63	7.64
	Capacity(kW) Silent	12.52	14.55	15.85	14.55	15.85
	COP Silent	10.15	10.17	10.18	10.17	10.18
Air35℃/Water28℃ Humidity 80%	Capacity(kW)	5.8 ~13.9	6.2~16.0	7.2~17.5	6.2~16.0	7.2~17.5
	Power input(kW)	0.8~3.35	0.82~3.73	0.97~4.17	0.82~3.73	0.97~4.17
	EER	4.15~7.22	4.29~7.54	4.21~7.44	4.29~7.54	4.21~7.44
	Capacity(kW) Boost	13.90	16.00	17.50	16.00	17.50
	EER Boost	4.15	4.29	4.21	4.29	4.21
	Capacity(kW) Smart	11.10	12.80	14.00	12.80	14.00
	EER Smart	5.18	5.36	5.26	5.36	5.26
	Capacity(kW) Silent	6.95	8.00	8.75	8.00	8.75
	EER Silent	6.40	6.60	6.48	6.60	6.48
power supply	V / Ph / Hz	380-415, 3N~, 50/60	220-240~, 50/60		380-415, 3N~, 50/60	
max current	A	6.51	29.6	31.3	9.87	10.4
water flow	m³/h	8~11	9~12	12~15	9~12	12~15
Refrigerant volume		R32				
Min pressure/max pressure	MPa	1.5/4.15				
Operating air temperature	℃	-15~43				
compressor brand		GMCC				
compressor type		Rotary				
water proof level		IPX4				
package dimensions	L x W x H(mm)	1076*426*720	1176*451*822			
unit dimensions	L x W x H(mm)	1161*490*855	1261*515*957			
noise at 1 m	dB(A)	44.7~54.9	45.6~57.1	47.2~59.7	45.6~57.1	47.2~59.7
noise at 10 m	dB(A)	24.6~33.7	26.6~36.5	27.3~38.2	26.6~36.5	27.3~38.2

Recycling

ENVIRONMENTAL INFORMATION

This equipment contains fluorinated greenhouse gases covered by the Kyoto Protocol. It should only be serviced or dismantled by professional trained personnel.

This equipment contains R32 (formula: CH_2F_2) refrigerant in the amount as stated in the specification. Do not vent R32 into the atmosphere: R32 is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 675.

DISPOSAL REQUIREMENTS

Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.




Your product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and other parts must be done by a qualified installer in accordance with relevant local and national legislation.

YOU HAVE THREE SOLUTIONS:

1. Disposing of it at your local recycling centre
2. Giving it to a social service organisation for it to be repaired and put back into circulation.
3. Returning it to the heat pump distributor against a new purchase.



902000100304

作图日期2024. 11. 27

SMS-BS-KY-250N8SBP-W01-01

本文件黑白印刷。

注意：本页不用印刷，仅对印刷颜色做要求。